

TITEBIKE™ .com

Yamaha YZF 2006-2007 R6 Frame Sliders

INSTALLATION INSTRUCTIONS

Right side installation:

1. Remove the stock motor mount bolt, set aside as it is no longer needed
2. Take the 90mm bolt and the longest aluminum insert and slide them both into the *shorter* of the two plastic sliders.
3. Put a drop of oil or anti-seize compound on the bolt threads and install the slider assembly into the now vacant motor mount location.
4. Torque to 25.0ft lbs. Do Not Over-tighten!



Left side installation:

1. Remove the mid fairing from the left side of the motorcycle
2. Remove the stock motor mount bolt, save it as it will be re-used.
3. Bolt the aluminum offset plate to the motor mount location using the 60mm bolt provided, blue lock tight and torque to 25.0ft lbs. The threaded hole in the offset plate should be facing toward the radiator.
4. Slide the remaining bolt, and aluminum insert thru the plastic slider and mount to the offset plate using a drop of blue lock tight and torque to 25.0ft lbs.



It is recommended that the purchaser use a qualified technician to install any parts. Purchaser recognizes that any modification of a vehicle may increase the risk of injury or accident, and will hold harmless all parties involved in this purchase.

WWW.TITEBIKE.COM
11757 W. KEN CARYL AVE.
#F-129
LITTLETON, CO 80127
SERVICE@TITEBIKE.COM
(720) 891-4907