

# TITEBIKE™ .com

## Suzuki GSXR 1000 2005-2006 Rearset Lowering Plates

### INSTALLATION INSTRUCTIONS

1. Separate the right and the left lowering plates. The right plate has a notch at the top, and the bolt holes are offset slightly for clearance of the rear brake master- cylinder. The offset is .100" (one hundred thousandths of an inch) and is not noticeable when you ride. The left side is symmetrical. Place the short length of hose with the right side.
2. Left side: Install the left side plate with the large counter sunk holes upright and the rounded edges facing outward, using the supplied bolts. Now install the rear- set onto the plate with the factory bolts.
3. Right side: Install the right plate with the notch facing up; it should also be facing toward the back of the motorcycle. Use the bolts provided to secure the plate. It may be necessary to replace the factory brake hose if it is stretched too much (this is the short black hose that goes between the brake reservoir and the master -cylinder) with the longer hose provided. Install the right rear-set to the plate with the factory bolts. If you have replaced the brake hose, it is recommended that you replace the old brake fluid with new fluid and bleed the rear brake system. You are done!



Any modification to a motorcycle is dangerous and buyer understands and accepts these risks. Buyer releases seller from all liability and acknowledges that a factory-trained technician should perform all modifications listed above. Ride smart and wear a helmet!

[WWW.TITEBIKE.COM](http://WWW.TITEBIKE.COM)  
11757 W. KEN CARYL AVE.  
#F-129  
LITTLETON, CO 80127  
SERVICE@TITEBIKE.COM  
(720) 891-4907